





N1735-Z (# 19130)

Zoom gear for AF-S Nikkor 17-35mm 1:2.8G ED



Please follow the instruction below to mount the N1735 - Z on the lens



1. Remove the rubber ring from the lens carefully.



2. Insert the plastic c-ring of the N1735-Z onto the rubber ring recess of the lens.



3. Insert the gear ring of the N1735-Z on the plastic c-ring, as shown in the diagram, until it reaches the flange of the plastic c-ring.

4. The tightness between the N1735-Z gear and the lens can be adjusted by removing or adding rubber grips on either sides of the plastic c-ring, spare rubber grips are included in the package.