

36476 N100 X1545PZ-Z Zoom Gear for Fujifilm XC 15-45mm f3.5-5.6 OIS PZ

Instruction Manual

FOREWORD

Thank you for your purchase of a NAUTICAM product.

At NAUTICAM, we pride ourselves in the ability to recognize the requirements of professional as well as amateur underwater photographers and fulfill them through the innovative designs of our products. We strive to achieve a high level of user-friendliness by allowing stress-free installation and easy operation of all important functions of the camera.

Please read this manual carefully before using the product, this will maximize its performance as well as its lifetime.

WARRANTY

All NAUTICAM Products are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.


To return your product for service, please contact your regional authorized service centre(s). Please note that this warranty only applies when the product is purchased in the territory where the service centre is located.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.

IDENTIFICATION OF PARTS



MOUNTING THE GEAR ON A LENS



1. Insert the plastic c-ring as shown and place it over the lens zoom ring.



2. Insert the N100 X1545PZ-Z Zoom gear on the plastic c-ring until it reaches the flange of the plastic c-ring.

To remove the N100 X1545PZ-Z Zoom gear, reverse the above steps.

3. The tightness between the N100 X1545PZ-Z Zoom gear and the lens can be adjusted by removing or adding rubber grips on either sides of the plastic c-ring, spare rubber grips are included in the package.

**Tips: After zoomed in or out, retract the zoom knob to its original position.

SPECIFICATIONS

Dimensions:	Dia87mm×23.9mm
Type:	Zoom gear
Compatible lens:	Fujifilm XC 15-45mm f3.5-5.6 OIS PZ

Remark: All Nauticam product manual will be changed to e-manual in end of 2018. Please download corresponding product manuals on Nauticam.com website, or contact us for e-manuals.