

## 36067 O1442-F Focus Gear for Olympus M.Zuiko Digital 14-42mm F3.5-5.6 II

### Instruction Manual

#### FOREWORD

Thank you for your purchase of a NAUTICAM product.

At NAUTICAM, we pride ourselves in the ability to recognize the requirements of professional as well as amateur underwater photographers and fulfill them through the innovative designs of our products. We strive to achieve a high level of user-friendliness by allowing stress-free installation and easy operation of all important functions of the camera.

Please read this manual carefully before using the product, this will maximize its performance as well as its lifetime.

#### WARRANTY

All NAUTICAM Products are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.

To return your product for service, please contact your regional authorized service center(s). Please note that this warranty only applies when the product is purchased in the territory where the service center is located.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.

#### IDENTIFICATION OF PARTS



#### MOUNTING THE GEAR ON A LENS



1. Insert the plastic C-ring as shown and place it over the lens' focus control ring .



2. Insert the O1442-F Focus gear on the plastic C-ring until it reaches the flange of the plastic C-ring.



3. To remove the O1442-F Focus gear, reverse the above steps.

The tightness between the O1442-F Focus gear and the lens can be adjusted by removing or adding rubber grips on either side of the plastic C-ring.

#### CONTROLLING THE GEAR

1. The O1442-F Focus gear can be controlled through the focus knob on a macro port, such as #36166 (N85 Macro Port 56 with Focus Knob)  
After mount the camera and lens gear into the housing and port, confirm that the focus knob operates correctly. Zoom function is controlled through the housing zoom knob.



#### SPECIFICATIONS

|                  |   |
|------------------|---|
| Dimensions:      | DIA 74 x 18.75 mm                           |
| Type:            | Focus gear                                  |
| Compatible lens: | Olympus M.Zuiko Digital 14-42mm F3.5-5.6 II |

Remark: Nauticam supports only e-manuals. Please download corresponding product manuals on [Nauticam.com](http://Nauticam.com) website, or contact us for e-manuals.